

BAIC

Immobiliser

E Series

Read key information

Program keys

Erase keys

Erase key 1

Erase key 2

Erase key 3

Erase key 4

Erase key 5

Erase key 6

Erase key 7

Erase key 8

Huansu 3

Basic function

Identification data

Fault codes

Erase DTC

System state

Program function

Set security code

Program date

Program VIN

Erase keys

Program keys

Reset immobiliser

Reset engine ECU

Replace engine ECU

Replace immobiliser ECU

PEPS

C70G/D70

Program keys

C50E/D50

Program keys

C60F/D60

Program keys

C61X/D61

Program keys

D280

Program keys