

Immobiliser Function List			
Software Version: 26.02			
Automaker	Model	System	Function
HAFEI	Type 1	Immobiliser	1.ECU identification 2.Read DTC 3.Clear DTC 4.Read data stream 5.Program function 6.Actuation test
HAFEI	Type 2	Immobiliser	1.Read DTC 2.Clear DTC 3.Read data stream 4.Program keys 5.Reset immobiliser
HAFEI		Match Remote Controller	