

Immobiliser Function List

Software Version: 26.11

| Automaker | System | Function |
|-----------|----------------------|--|
| QNLOTUS | Siemens Immobiliser | <ul style="list-style-type: none"> 1. ECU identification 2. Fault codes 3. Erase DTC 4. Live data 5. Set security code Program function 6. Program new system 7. Program keys 8. Erase keys 9. Replace immobiliser ECU 10. Replace engine ECU 11. Program immobiliser VIN 12. Program engine VIN 13. Reset engine ECU 14. Reset immobiliser |
| QNLOTUS | Original Immobiliser | <ul style="list-style-type: none"> 1. ECU identification 2. Fault codes 3. Erase DTC 4. Live data Program function 5. Program keys 6. Erase keys |

| | | |
|---------|------------------|--|
| QNLOTUS | DIAS Immobiliser | <ul style="list-style-type: none">1. ECU identification2. Fault codes3. Erase DTC4. Live dataProgram function5. Add a key6. Erase keys7. Program new system8. Replace immobiliser ECU9. Replace engine ECU10. Reset immobiliser11. Reset engine ECU12. Read VIN13. Check key14. Check engine ECU15. Program engine VIN16. Program immobiliser VIN17. Lock immobiliserActuation test18. LED status |
|---------|------------------|--|