

## ASTRA Test Function List

| manufacturer | vehicle / model number |                     | system/electronic control | diagnosis interface | system information | read code | clear code | read data | actuation test | specific function |
|--------------|------------------------|---------------------|---------------------------|---------------------|--------------------|-----------|------------|-----------|----------------|-------------------|
| <b>ASTRA</b> | ADT                    | ENGINE              | DIESEL INJECTION          | OBD/IVECO30         | √                  | √         | √          | √         | √              |                   |
|              | HD7                    | ENGINE              | DIESEL INJECTION          | OBD/IVECO30         | √                  | √         | √          | √         | √              |                   |
|              | HD8                    | ENGINE              | DIESEL INJECTION          | OBD/IVECO30         | √                  | √         | √          | √         | √              |                   |
|              |                        | CHASSIS             | ABS                       | OBD/IVECO30         | √                  | √         | √          | √         | √              |                   |
|              |                        |                     | EBS                       | OBD/IVECO30         | √                  | √         | √          | √         | √              |                   |
|              |                        | BRAKE POWER SUPPORT | OBD/IVECO30               | √                   | √                  | √         | √          | √         |                |                   |
|              | Military vehicl        | ENGINE              | DIESEL INJECTION          | OBD/IVECO30         | √                  | √         | √          | √         | √              |                   |
|              |                        | CHASSIS             | ABS                       | OBD/IVECO30         | √                  | √         | √          | √         | √              |                   |
|              |                        |                     | BRAKE POWER SUPPORT       | OBD/IVECO30         | √                  | √         | √          | √         | √              |                   |

[www.JOBD2.jp](http://www.JOBD2.jp)