

Immobiliser Function List

Software Version: 26.32

Automaker	Model	System	Function
ROEWE	350 (-2012)	Immobiliser	1. Add a key 2. Erase keys
ROEWE	350 (2013-)	Immobiliser	1. Add a key 2. Erase keys
ROEWE	550	Immobiliser	1. Add a key 2. Erase keys
ROEWE	950	Immobiliser	1. All smart keys lost 2. Erase DTC 3. Live data
ROEWE	W5 (Type 1)	Immobiliser	1. Add a key 2. Erase keys
ROEWE	W5 (Type 2)	Immobiliser	1. Add a key 2. Erase keys
ROEWE	750	Remote	1. Program remote 2. Read remote ID 3. Disable remote 4. Enable remote 5. Erase DTC